

VIEW AT CENTER SUPPORT

CENTER VESSEL ON 2 OR 3 SUPPORTS AT SPAN(S)"S"; 3 SUPPORTS REQUIRED FOR LENGTHS -4 AND OVER

Dwg. Qty. Part

(1)

(2) 2 50663

(3) 2

(4) 2

(5) 2

(6) 2 45320

 $\overline{(7)}$ 2 45350

(8)

(9) 2 50676

(0)

(11)*3 45102

(12) *3 45042

(3)

(14) 2

(5)

(16) 2 45308

6 50758

6 45228

4 46265

1 50214

Ref. Per Number Part Name

50667

50671

45248

Shell

Bearing Plate

Sealing Plate

Permegte Port

Perm Port Seal

Locking Ring

Securing Ring

Saddle

As Required Adapter

4 As Required PWT Seal

Strap Assy

Strap Screw

Adapter Seal

*2 each furnished with length code 1, 2 & 3.

Port Retainer

Head Seal

SHELL

HEAD

HEAD INTERLOCK

Securing Screws 316 Stainless Steel

VESSEL SUPPORT

ELEMENT INTERFACE

Thrust Ring Assy Engineering Thermoplastic

Materials/Remarks

Filament wound epoxy/glass composite-

Head locking grooves integrally wound in-place, with 316 SS F/C side-ports.

6061-T6 aluminum alloy-hard anodized

304 Stainless Steel, Truarc type

Ethylene Propylene, Quad Ring

Ethylene Propylene, square-cut

Cast Aluminum-hard anodized

Engineering Thermoplastic

Engineering Thermoplastic

Ethylene Propylene - 0-Ring

Ethylene Propylene - 0-Ring

18-8 Stainless Steel

Reinforced Plastic - Yellow Color

304 Stainless Steel - PVC cushion

PVC Thermoplastic

PVC Thermoplastic

CAUTION-INCORRECT MANIFOLDING WILL CAUSE SEVERE LOCAL STRESS AROUND PORT AND MAY RESULT IN LEAKS AND PREMATURE FAILURE; TAKE EVERY PRECAUTION LISTED ON REVERSE, SEE INSTALLATION INSTRUCTIONS FOR FURTHER DETAILS

(14)(16)(4` WARNING! INTERNAL PORT PRESSURE MUST NOT EXCEED 125 PSI

SECTION THROUGH END CLOSURE

ITEM (15) DOWNSTREAM ONLY

ASME CODE NAMEPLATE (OPT.)

ADVANCED STRUCTURES, INC. CLASS ESCONDIDO, CALIFORNIA U.S.A. MAX.W.P. 400 P.S.I. 120°F. MIN.OPER.TEMP.20 °F. MFG.SER. YR.BLT.

NOTES

- · SHELL EXTERIOR COATED WITH WHITE, HIGH GLOSS POLYURETHANE PAINT
- DIMENSION IN INCHES (MM APPROX.)
- NOT TO BE USED FOR CONSTRUCTION UNLESS CERTIFIED

Length Code	L.O.A. IN (MM)	Port to Port IN (MM)	Span IN (MM)	Weight LB (KG)	
1	58.0 (1473)	45.0 (1143)	28 X 1 (711)	60 (27)	
2	98.0 (2489)	85.0 (2159)	56 X 1 (1422)	80 (36)	
3	138.0 (3505)	125.0 (3175)	80 X 1 (2032)	100 (45)	
4	178.0 (4521)	165.0 (4191)	64 X 2 (1626)	120 (54)	
5	218.0 (5537)	205.0 (5207)	78 X 2 (1981)	140 (63)	
6	258.0 (6553)	245.0 (6223)	92 X 2 (2337)	160 (73)	
7	298.0 (7569)	285.0 (7239)	106 X 2 (2692)	180 (82)	
7.5	318.0	305.0	114 X 2	190	

 \triangleright

Shell

7.5

(8077)

338.0

(8585)

S

(2896)

120 X 2

(3048)

Empty

(87)

200

(92)

STRUCTURAL GROUP

(7747)

325.0

(8255)

ENGR AP 04MAY99		MODEL E8L/SP w pressure ro pressure vessel sidewall porting			
QLTY RAP 14MAY99	LOW				
MRKT	EC0	SHEET	SIZE	NUMBER	REV
DWE 11MAY99	89711	1 0F 1	В	507016	J

RATING:

DESIGN PRESSURE 400 PSI at 120°F (2.8 MPa at 49°C)
MIN. OPERATING TEMP20°F (-7°C)
FACTORY TEST PRESSURE 600 PSI (4.1 MPa)
BURST PRESSURE 2400 PSI (16.5 MPa)

INTENDED USE

The Model E8L/SPFiberglass R0 Pressure Vessel is designed for continuous, long—term use as a housing for reverse osmosis membrane elements to desalt typical brackish waters at pressures up to 400 psi. Any make of eight—inch nominal diameter spiral—wound element is easily accommodated; the appropriate interfacing hardware for the element specified is furnished with the vessel.

The model EBL/SP is designed in accordance with the engineering standards of the Boiler and Pressure Vessel Code of the American Society of Mechanical Engineers (ASME Code). At small additional cost, vessels can be inspected during construction by an ASME Authorized Inspector and ASME Code stamped.

The Model E8L/SP must be installed, operated and maintained in accordance with the precautions listed and good industrial practice to assure safe operation over a long service life.

The high performance reinforced plastic shell must be allowed to expand under pressure; undue restraint at support points or piping connections can cause leaks to develop in the shell. This side—ported vessel requires special precautions in mounting and connection to piping so that the vessel will not be subjected to excessive stress due to bending moments acting at the side openings in the fiberglass shell.

The end closures, incorporating close—fitting, interlock—ing metal components, must be kept dry and free of corrosion; deterioration can lead to catastrophic mechanical failure of the heads.

Structural Group will assist the purchaser in determining the suitability of this standard vessel for their specific operating conditions. The final determination however, including evaluation of the standard materials of construction for compatibility with the specific corrosive environment, shall be the responsibil—ty of the purchaser. Alternate materials with enhanced corrosion resistance are available on special order.

Specifications subject to change without notice.

PRECAUTIONS

- DO... read, understand and follow all instructions; failure to take every precaution will void warranty and may result in vessel failure
- DO... mount shell centered on horizontal members spaced at recomended span(s) "S" using compliant mounting hardware furnished; tighten hold down straps just snua
- DO... align and center side ports with the manifold header; correct causes of misalignment in a row of vessels connected to the same header
- DO... use flexible type grooved—end pipe couplings, Victaulic® Style 75 or equal, at sideports; allow full .125 inch gap between port and piping, and position piping to maximize flexibility of connection
- DO... provide flexibility in, and support for piping manifold so that vessel can grow in length under pressure without undue restraint; provide additional flexible joints in large pipes leading to manifold header
- DO... provide overpressure protection for vessel set at not more than 105% of design pressure
- DO... inspect end closures regularly; replace components that have deteriorated and correct causes of corrosion
- DO NOT...work on any component until first verifying that pressure is relieved from vessel
- DO NOT...make rigid piping connections to ports or clamp vessel in any way that restricts growth of fiberglass shell under pressure; ▲DIA = 0.015 in. (0.4mm) and ▲L = 0.25 in. (6mm) for a length code -8 vessel
- DO NOT...hang piping manifolds from ports or use vessel in any way to support other components
- DO NOT...tighten Permeate Port connection more than one turn past hand tight
- DO NOT...operate vessel without connecting both Permeate Ports internally to a complete set of elements or otherwise plug ports internally so that external piping connection is not subjected to feed pressure
- DO NOT...install Spacer on downstream end of vessel
- DO NOT...operate vessel without Thrust Ring installed downstream
- DO NOT...pressurize vessel until double checking to verify that all three segments of Locking Ring Set are in place, and that the Securing Ring is fully seated and secured by all three Securing Screws
- DO NOT...operate vessel at pressures and temperatures in excess of its rating
- DO NOT...operate vessel with permeate pressure in excess of 125 psi at 120°F (0.9 MPa at 49°C)
- DO NOT...tolerate leaks or allow end closures to be routinely wetted in any way

ORDERING

Please specify the following:

- VESSEL MODEL NUMBER built from table of options below
- MEMBRANE FLEMENT MODEL NUMBER
- SPECIFIC CONCERNS regarding INTENDED USE and requests for SPECIAL MATERIALS of CONSTRUCTION

A vessel model number specifies a complete assembly less element interface components. The required interface components are furnished with the vessel but are specified separately.

Membrane elements and between-element connectors (interconnectors) are furnished by membrane element manufacturer.

